

PC Kit *and* Power Set

Data acquisition and data processing with *mobifinder*[®]
Power supply for *mobifinder*[®]

mobifinder-PC Kit

- Simple recording of all alarms including date, time, field strength and user chosen identification for security minutes and flight reports for Laptop or PC.
- Simple minutes drawing up by integration of measured values in text- or spreadsheet-program. (Automated drawing up of minutes)
- Automated time- and date alignment of *mobifinder*[®]
- Blocking of *mobifinder*[®] eligible functions by button (set user level)

mobifinder-PC Kit enables simple data acquisition of all by *mobifinder*[®] recorded measure values. Values can be transmitted to PC and stored into a data file or transmitted to other programs (e.g. spreadsheet-programs or data base systems (dbs)).



No.	date	time	value	user ID
182	08.04.	13:57:22	new user ID	123456
183	08.04.	13:57:56	78dB	123456
184	08.04.	13:58:34	new user ID	225566
185	08.04.	13:58:08	68dB	225566
186	08.04.	13:58:09	68dB	225566
187	08.04.	13:58:33	78dB	225566
188	08.04.	13:58:35	78dB	225566
189	08.04.	13:58:36	77dB	225566
190	08.04.	13:58:38	77dB	225566
191	08.04.	13:58:39	80dB	225566
192	08.04.	13:58:41	76dB	225566
193	08.04.	14:01:18	new user ID	307636
194	08.04.	14:01:51	51dB	307636
195	08.04.	14:05:34	55dB	307636

Main functions

mobifinder[®] measured values can be transmitted to PC and stored there.
Automated time function.
Simplified operation mode possible.

Use

Mobile device with standard RS 232-cable useable for Laptop and PC.
Power supply by battery or plug-in power pack.
Operation by PC.
PC Software (on CD-ROM) included.

Body

dimensions (mm): 103 x 178 x 48
weight: 420g
LED shows operational readiness
on/off-switch
battery compartment (9V)
Sub-D-gland for data com to PC
socket for power supply through
power supply unit

Power Set PC Kit *and* Set

Power supply for *mobifinder*[®]

Data acquisition and data processing with *mobifinder*[®]

***mobi*-Power Set**

mobifinder[®]

- changes into a stationary appliance
- can be used without batteries
- attachable with the swanneck on table and wall
- is adjustable horizontal and vertical in the line of sight



With *mobi-Power Set* you can use *mobifinder*[®] in closed rooms and without batteries. For wall or table adjustment a swanneck is used. Then *mobifinder*[®] is supplied with power through the delivered mains power supply.

Technical data

Power supply over mains power supply

Input: 230V/50Hz/11W

Output: 6V/500mA

dealer